



Thanks for purchasing a Juicebox!  
To ensure best results, please  
read the following instructions  
before use.

## SETUP

Always use the provided nylon washer when attaching the double-sided screw, or any screw longer than 1/8", to the battery. The Magic Power™ is designed with standard, 1/4-20 and 3/8" threaded holes for attaching your preferred mounting device. We recommend the use of a rod clamp or quick release plate for easy attachment/detachment of the battery to your Blackmagic® rig.

## OPERATION

For best results, charge the battery before each use, including the first use. The Magic Power™ has both an "In" and "Out" port as well as an "On/Off" switch. To charge the battery, connect the provided charger to the "In" port and turn the switch to the "On" position. To power the camera, connect the battery to the camera using the "Out" port and one of the provided male-to-male power cables.

## IN THE BOX:



## SUPPORT

Thank you for purchasing a Juicebox! Our goal is to provide high quality, low cost power sources for your film gear. We believe that the democratization of film begins with an affordable price tag. We'd love to hear from you! Please send feedback or support questions to [support@juicebox.direct](mailto:support@juicebox.direct). And, if you've found this product helpful, please take the time to review us online. We appreciate it!

JUICEBOX.DIRECT